

<b>Natural Gas</b>		<b>L.P.G.</b>	<i>Serial No:</i>			
<i>MODEL:</i>	<i>MB055</i>	<i>MB105</i>	<i>MB155</i>	<i>MB185</i>	<i>MB265</i>	<i>MB405</i>

**WARNING:** If the information in these instructions are not followed exactly, a fire or explosion may result causing property damage, personal injury or death.

- Do not store or use gasoline or other flammable vapours and liquids in the vicinity of this or any other appliance.
- **WHAT TO DO IF YOU SMELL GAS**
  - Do not try to light any appliance.
  - Do not touch any electrical switch; do not use any phone in your building.
  - Immediately call your gas supplier from a neighbour's phone. Follow the gas supplier's instructions.
- Installation and service must be performed by a Corgi registered installer, service agency or the gas supplier.



**MB055**



**MB105**



**MB155**



**MB185 - MB265 - MB405**



**Operating, Installation and  
Servicing Instructions for**

**Certikin**

***Pool & Spa Heaters***

**Models:**

***MB055***

***MB105***

***MB155***

***MB185***

***MB265***

***MB405***

GENERAL SPECIFICATIONS							
WATER CONTENT	Litre (gal)	Model 055	0.8 (0.18)	Model 105	1.1 (0.3)	Model 155	1.8 (0.4)
		Model 185	1.9 (0.4)	Model 265	1.9 (0.4)	Model 405	2.6 (0.5)
MAXIMUM WATER PRESSURE		8 bar (125 psi)					
MAXIMUM WATER FLOW TEMP		45.0 °C 110 (°F)					
ELECTRICAL SUPPLY		230V 50Hz, FUSED AT 3A. POWER 100W					

PERFORMANCE SPECIFICATIONS - NATURAL GAS							
GAS CATEGORY, TYPE AND SUPPLY PRESSURE				II <sub>2H3+</sub> G20 @ 20 mbar (8 in. wg)			
MODEL		055	105	155	185	265	405
BURNER PRESSURE mbar (in. wg)		6.3 ( 2.5 )	6.8 ( 2.7 )	7.7 ( 3.1 )	8.1 (3.2)	8.3 (3.3)	8.7 (3.5)
HEAT INPUT	GROSS kW (Btu/h)	12.9 (44,000)	26.67 (91,000)	38.98 (133,000)	49.53 (169,000)	71.5 (244,000)	108.4 (370,000)
	NET kW (Btu/h)	11.6 (39,600)	24.0 (81,900)	35.08 (119,700)	44.58 (152,100)	64.4 (219,600)	97.6 (333,000)
HEAT OUTPUT kW (Btu/h)		10.06 (34,300)	20.8 (71,000)	30.4 (103,700)	38.63 (131,820)	55.8 (190,300)	84.58 (288,600)
GAS RATE m³/h		1.22	2.5	3.7	4.6	6.6	10.28
INJECTOR DIA. mm & (MARKING) gauge		1.78 (50)	1.78 (50)	1.85 (49)	1.78 (50)	1.78 (50)	1.78 (50)
NUMBER OF BURNERS & INJECTORS		4	8	10	13	19	29

PERFORMANCE SPECIFICATIONS - LPG									
GAS CATEGORY, TYPE AND SUPPLY PRESSURE					II <sub>2H3+</sub> G30 @ 30 mbar, G31 @ 37 mbar				
MODEL		055 Easiheat		055	105	155	185	265	405
HEAT INPUT	GROSS kW (Btu/h)	14.65 (50,000)	12.9 (44,000)	26.67 (91,000)	38.98 (133,000)	49.53 (169,000)	71.5 (244,000)	108.4 (370,000)	
	NET kW (Btu/h)	13.2 (45,000)	11.9 (40,500)	24.54 (83,720)	35.86 (122,360)	45.57 (155,480)	65.8 (224,480)	99.8 (340,400)	
HEAT OUTPUT kW (Btu/h)		11.0 (37,400)	10.06 (34,300)	20.8 (71,000)	30.4 (103,700)	38.63 (131,820)	55.8 (190,300)	84.58 (288,600)	
GAS RATE m³/h		0.50	0.47	0.97	1.43	1.82	2.57	4.04	
INJECTOR DIA. mm & (MARKING) gauge		1.01 (60)	0.99 (61)	0.99 (61)	1.01 (60)	1.01 (60)	1.01 (60)	1.01 (60)	
NUMBER OF BURNERS & INJECTORS		4	4	8	10	13	19	29	

# Contents

## INSIDE COVER - GENERAL & PERFORMANCE SPECIFICATIONS

### 2 PART ONE - USER'S OPERATING INSTRUCTIONS

#### 2 SECTION 1 / START-UP PROCEDURES

- 2 Before Start-Up
- 3 Operating Models 055, 105 AND 155
- 4 Operating Models 185, 265 and 405
- 5 After Start-Up

#### 5 SECTION 2 / CAUTION

#### 5 SECTION 3 / MAINTENANCE & CARE PROCEDURE

- 6 Pool & Spa Water Chemistry
- 6 Cold Weather Operation
- 6 Winterizing the Pool & Spa Heater

### 7 PART TWO - INSTALLATION/SERVICE INSTRUCTIONS

#### 7 SECTION 1 / RECEIVING EQUIPMENT

#### 7 SECTION 2 / INSTALLATION INSTRUCTIONS

- 11 Outdoor Heaters
- 11 Indoor Heaters
- 14 Combustion Air
- 15 Gas Supply Connections
- 16 Plumbing For Water Connections
- 16 Left Side Water Connection Conversion
- 20 Electrical Wiring

#### 23 SECTION 3 / SERVICING INSTRUCTIONS

- 23 General Location of Controls
- 25 Temperature Controls
- 25 Pressure Switch
- 26 High Limit
- 27 Pilot Safety
- 27 Burner Drawer Removal
- 27 Gas Valve Removal
- 27 Main Burner & Orifice Removal
- 27 Pilot Removal & Cleaning
- 28 Heat Exchanger Removal
- 28 Control Immersion Well Replacement
- 28 Tube Cleaning
- 29 Desooting Procedure
- 29 Combustion Chamber Removal
- 29 Unitherm Governor Replacement

#### 30 SECTION 4 / TROUBLE SHOOTING GUIDE

- 30 Mechanical
- 32 Models 055, 105 & 155.
- 34 Models 185, 265 & 405.

#### 36 SECTION 5 / REPLACEMENT PARTS

- 36 Replacement Parts List - 055
- 38 Replacement Parts List - 105
- 40 Replacement Parts List - 155
- 42 Replacement Parts List - 185, 265 & 405

# PART ONE - USER'S OPERATING INSTRUCTIONS

## FOR YOUR SAFETY - READ BEFORE OPERATING

**WARNING: IF YOU DO NOT FOLLOW THESE INSTRUCTIONS EXACTLY, A FIRE OR EXPLOSION MAY RESULT, CAUSING PROPERTY DAMAGE, PERSONAL INJURY OR LOSS OF LIFE.**

## SECTION 1 / START-UP PROCEDURES

### BEFORE START-UP

#### BURNERS

Clean air louvers of dust, lint and debris. Keep heater area clear and free from combustibles, flammable liquids and chemicals. Do not obstruct the flow of combustion and ventilating air.

#### WATER

Water must be flowing through the heater during operation. Ensure that system is filled with water and the pump is operating.



055



105



155



185 - 265 - 405

## ■ FOR YOUR SAFETY READ BEFORE OPERATING ■

**WARNING:** IF YOU DO NOT FOLLOW THESE INSTRUCTIONS EXACTLY, A FIRE OR EXPLOSION MAY RESULT CAUSING PROPERTY DAMAGE, PERSONAL INJURY OR LOSS OF LIFE.

This appliance is equipped with an ignition device which automatically lights the pilot. Do not try to light the pilot by hand.

**BEFORE OPERATING** after a prolonged off, smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

- \* **WHAT TO DO IF YOU SMELL GAS**
- \* Do not try to light any appliance
- \* Do not touch any electric switch
- \* Do not use any phone in your building.
- \* Immediately call your gas supplier from a neighbour's phone. Follow the gas supplier's instructions.
- \* If you cannot reach your gas supplier, call the fire service.

Isolate the appliance with the Service Cock inside. If this is not accessible, isolate at the gas meter.

Do not use this appliance if any part has been under water. Immediately call a qualified service engineer to inspect the appliance and to replace any part of the control system and any gas control which has been under water.

**CAUTION:** Propane gas is heavier than air and will settle on the ground. Since propane can accumulate in confined areas, extra care should be exercised when lighting propane heaters.



### OPERATING MODELS 055,105 and 155

#### Quick Start

Check that the Electricity and Gas Supplies are on. Turn on the Pool Pump. Turn on the Heater with the switch on the Front Panel and set the desired temperature with the Pool Temperature Knob. In a few seconds the Heater will fire.

#### Summary of Controls (Left to Right)


##### Pool Temperature Control Knob

16°C to 41°C (60°F to 106°F)

The Pool or Spa water temperature is controlled by the Pool Temperature Knob, rotate anti-clockwise to increase the Pool Temperature.

The Knob is fitted with a means of limiting the upper temperature limit below the maximum level.

The knob stop adjustment ring illustrated is adjustable by loosening the set screw, rotating the knobstop ring to the desired location and retightening the set screw.



#### High Limit

If the Heater temperature rises too high the High Limit Thermostat will operate. Wait until the Heater is cool then press 'Reset'. It will click if it has had to reset. The Heater should now run.

If this problem persists this should be investigated by a Service Engineer.

**ON/OFF Switch** - Turns the Heater On and Off and resets the Ignition Control if locked out. For longer periods of isolation the Heater should be switched off at its Mains supply.

## OPERATING MODELS 185, 265 and 405




### Quick Start

Check that the Electricity and Gas Supplies are on. Turn on the Pool Pump. Turn on the Heater with the switch on the Front Panel and set the desired temperature with the Pool Temperature Knob. In a few seconds the Heater will fire.

### Summary of Controls (Left to Right)

**ON/OFF Switch** - Turns the Heater On and Off and resets the Ignition Control if locked out.

 **Lock/Unlock Button** - If it is pressed for 2 seconds it locks the Set Temperature so the Pool Temperature Knob is inoperative. To unlock, press again for 2 seconds. With a short press the Set temperature is displayed. It will flash if the Lock is ON.

**Pool Temperature Display** - This normally shows the Pool Temperature but also show the Setting Temperature when the Pool Temperature Control Knob is moved. A Setting Dot is displayed whilst it is adjusted. The Display is also used for commissioning and diagnostic purposes.

(Page 34)

### Pool Demand LED - Green

**Off** - There is no Pool Heating demand, pool heating is off.

**On** - There is Pool Heating Demand and the Pool is not up to temperature.

**Flashing** - The Pool Heating Demand is met, the pool is up to temperature.

### Pool Temperature Control Knob

16°C to 32°C or 41°C (60°F to 90°F or 106°F)

(Maximum is changed in Setup Mode, see Page 34)

Rotate clockwise to increase the Pool Temperature. The Setting Temperature is shown whilst rotating and for 3 seconds after.

To lock the required Temperature Setting see

**Lock/Unlock Button.**



### Pool Filter Blocked - Yellow

On - If the pump is running and there is insufficient pressure, possibly due to a blocked Pool Filter. The Heater will not run.

### Overheat - Red

On - This indicates the Heater has overheated and shutdown. Use the Overheat Reset (see below). If this problem persists this should be investigated by a Service Engineer.

### Overheat Reset (not on front panel)

If the Overheat Indicator has lit the Heater will not work until the thermostat has been reset. (See page 24 for location)

Wait until the Heater is cool then remove the door and locate the Overheat Thermostat mounted on its bracket. Press its centre and it will click.

The Red Overheat indicator will go out and the Heater can now run.



## AFTER START-UP


Feel the inlet and outlet pipes. Outlet pipe should be only slightly warmer than the inlet. It should not be hot.

**WARNING:** *Should overheating occur or the gas supply fail to shut off, turn off the manual gas control to the appliance.*



### VISUAL INSPECTION

With the heater on, remove the door and make a visual check of the pilot and burner.

The flame should be blue with a well-defined pattern.



MAIN BURNER FLAME



PILOT BURNER FLAME

A yellow or "floating" flame indicates restricted air openings or incorrect injector size. Should this occur, shut the heater off and contact your installer or gas supplier.

### WATER PRESSURE SWITCH

A water pressure switch is provided in the heater to shut off the burners in the event that water supply to the heater is interrupted. It is very important to verify that the switch electrically opens and shuts off the gas valve when water flow to the heater is interrupted. Otherwise, rapid and severe damage is likely to occur to the heater. (The water pressure switch should be checked and adjusted for proper operation by a qualified service person at the time of installation checked thereafter.)

**WARNING:** *Operation of the heater without water circulation will cause rapid and severe damage to the heater.*

## SECTION 2 / CAUTION

Elevated water temperature can be hazardous, and the U. S. Consumer Product Safety Commission recommends the following guidelines:

1. Spa or hot tub water temperatures should never exceed 40°C (104°F). A temperature of 38°C (100°F) is considered safe for a healthy adult. Special caution is suggested for young children.
2. Drinking of alcoholic beverages before or during spa or hot tub use can cause drowsiness which could lead to unconsciousness and subsequently result in drowning.
3. *Pregnant Women Beware!* Soaking in water over 39°C (102°F) can cause fetal damage during the first three months of pregnancy resulting in the birth of a brain-damaged or deformed child. Pregnant women should stick to the 38°C (100°F) maximum rule.
4. Before entering the spa or hot tub, users should check the water temperature with an accurate thermometer; spa or hot tub thermostats may err in regulating water temperatures by as much as 2°C (4°F).
5. Persons with a medical history of heart disease, circulatory problems, diabetes, or blood pressure problems should obtain a physician's advice before using pools or hot tubs.
6. Persons taking medications which induce drowsiness, such as tranquilizers, antihistamines, or anticoagulant, should not use spas or hot tubs.

## SECTION 3 / MAINTENANCE AND CARE PROCEDURES

This heater casing is Polyester powder on top of zinc coated steel to assist in resisting corrosion. It is recommended that periodically the casing is cleaned and sprayed with WD40 or similar liquid especially when installed outdoors. Exposed threads on manifolds will benefit from a light coating of grease. Outdoor tops are finished with a special black high temperature coating and as this is part of the flueing system, subject to high temperatures and the elements, can discolour and corrode over a period of time.

A full service by a competent person (i.e. CORGI registered) should be conducted at least once a year.

1. Inspect top of heater and draughthood for soot, (a sticky black substance around finned tubes and "V" baffles), and open flue gas passage ways. If soot is present, contact installer or service agent.
2. Inspect and operate all controls, gas valve and pressure relief valve.

3. Make visual check of the burner and pilot flame. Flame pattern on the main burner and pilot is indicated in the previous illustration. Yellow flame means restriction of the air openings. Lifting or blowing flame indicates high gas pressure. Low flame means low gas pressure. Should this occur, shut the heater off and contact your gas supplier or qualified service agency.
4. On indoor heaters, clean room intake openings to assure adequate flow of combustion and ventilation air.

**CAUTION:** Combustion air must not be contaminated by corrosive chemical fumes which can damage the heater and void the warranty.

5. Keep area around heater clear and free from combustible materials, gasoline and other flammable and corrosive vapours and liquids.

## POOL & SPA WATER CHEMISTRY

**IMPORTANT!** These Heaters are not suitable for use on Salt Chlorinated pools. If this is intended please contact the Manufacturer.

Chemical imbalance can cause severe damage to your heater and associated equipment. Maintain your water pH between 7.4 and 7.8 and total alkalinity between 100 and 150 p.p.m. If the mineral content and dissolved solids in the water become too high, scale forms inside the heat exchanger tubes, reducing heater efficiency and also damaging the heater. If the pH drops below 7.2, the heater will be severely damaged. This will result in corrosion of the heat exchanger. **Heat exchanger damage resulting from chemical imbalance is not covered by the warranty.**

## AUTOMATIC CHLORINATORS AND CHEMICAL FEEDERS

All chemicals must be introduced and completely diluted into the pool or spa water before being circulated through the heater. Do not place chlorine tablets or bromine sticks in the skimmer. High chemical concentrations will result when the pump is not running (i.e. overnight).

Chlorinators must feed downstream of the heater and have an anti-siphoning device to prevent chemical back-up into the heater when the pump is shut off.

**NOTE:** High chemical concentrates from feeders and chlorinators that are out of adjustment will cause very rapid corrosion to the heat exchanger in the heaters. Such damage is not covered under the warranty.

## COLD WEATHER OPERATION

**MODERATE CLIMATE:** Heater operation can continue during short term cold spells. When temperatures are below freezing, flow (continuous pump operation) must be maintained.

**CAUTION:** Do not use the heater to maintain water temperatures just above freezing or for freeze protection. When heater is used during freezing weather, care must be taken to avoid freeze ups. Continuous pump operation is a must. Additional protection may be required. The heater is not warranted against freeze ups.


**COLD CLIMATE:** Prolonged operation with water temperatures below 10°C (50°F) is not recommended. When starting the heater with pool temperatures below 10°C (50°F) operate the heater continuously until higher temperatures are reached. Operating the heater for prolonged periods with pool water below 10°C (50°F) can seriously damage the heater, and is not covered by the warranty.

For cold climate areas, please follow the winterizing procedures listed.

## WINTERIZING THE POOL & SPA HEATER

When heaters installed outdoors in freezing climate areas are to be shut down for the winter, observe the following step-by-step procedure:

1. Turn off gas valve, manual gas valve, and electrical supply to the heater.
2. Open drain cock located on the inlet/outlet header, (under water pipes). Remove drain plug from return header. Remove the heat exchanger inspection panels on the side opposite water piping to gain access to the plug on the return header.



3. Disconnect compression fittings from the pressure switch and return header that connects to the 1/4" copper tube and allow the tube to drain.



# PART TWO - INSTALLATION/SERVICE INSTRUCTION

## SECTION 1 / RECEIVING EQUIPMENT

**WARNING:** This appliance must be installed and serviced by a CORGI registered installer.

On receipt of your equipment it is suggested that you visually check for external damage to the carton. If the carton is damaged, a note should be made on the delivery note when signing for equipment. Remove the heater from the carton and if it is damaged, report the damage to the carrier immediately. Save the carton.

These items are shipped loose inside the carton:

In the 055 & 105 heaters:

1. CPVC Adaptors (2)
2. Plastic Gaspipe Flange (1)

In the 155 heater:

1. In/Out Flanges (2)
2. 1-1/2" Flange Gaskets (2)
3. 2" Flange Gaskets (2)
4. Flange Bolts (4)
5. 2" CPVC Adaptors (2)

In the 185, 265 and 405 heaters:

1. Demountable adapters (2)
2. O Rings (2)

Be sure that you receive the number of packages indicated on the delivery note.

When ordering parts, you must specify model and serial number of heater. When ordering under warranty conditions, you must also specify date of installation.

It is recommended that this manual be reviewed thoroughly before installing your pool/spa heater. If there are any questions that this manual does not answer, please contact the supplier.

All heaters are inter-changeable and can be used either indoor or outdoors. The appropriate top designated for that type of use is required. If desired, the top can be changed at a later date to change from outdoor to indoor or vice versa.

**CAUTION:** It is perfectly normal during the first hours of operation for the ceramic boards in the combustion chamber to give off unpleasant odours. This clears permanently after three or four hours. Ensure the heater is properly and adequately ventilated during this period.

## SECTION 2 / INSTALLATION INSTRUCTIONS

### IMPORTANT NOTICE

These instructions are intended for the use of qualified personnel only, specifically trained and experienced in the installation of this type of heating equipment and related system components. Installation and service personnel must be CORGI registered. Persons not qualified must not attempt to fix this equipment nor attempt repairs according to these instructions.

### WARNING:

*Improper installation, adjustment, alteration, service or maintenance may damage the equipment, create a hazard resulting in asphyxiation, explosion or fire, and will void the warranty.*

### STATUTORY REQUIREMENTS

#### Gas Safety (Installation and Use) Regulations, 1994

It is the law that all gas appliances are installed by competent persons in accordance with the above regulations. Failure to install appliances correctly could lead to prosecution. It is in your own interest, and that of safety, to ensure that the law is complied with.

#### General Requirements

The appliance must be installed by a competent person ie. CORGI registered in accordance with the relevant requirements of the Gas Safety Regulations, current I.E.E. Regulations, Model Water Byelaws, Local Water Authority Byelaws and any relevant requirements of the local gas supplier, local authority and the relevant British Standard Codes of practice and Building Regulations. Manufacturers notes must not be taken in any way as overriding statutory obligations. Typical documents include:

#### Models 055, 105 & 155

- BS. 5440:1 Flues (for gas appliances of rated input not exceeding 60 KW).
- BS. 5440:2 Ventilation (for gas appliances of rated input not exceeding 60KW).
- BS. 5449 Forced circulation hot water systems.
- BS. 6798 Installation of gas fired hot water boilers of rated input not exceeding 60 KW.
- BS. 6891: Installation of low pressure pipework.
- Health & Safety Document No. 635.
- The Electricity at Work regulations, 1989.
- CP341; Water Supply.
- British Gas Publications:
  - IM2; Purging Procedures of Non-domestic Gas Installations
  - IM5, Soundness Testing Procedures for Industrial and Commercial Gas Installations.

#### Models 185, 265 & 405

- BS. 6891; Installation of low pressure pipework.
- BS. 6644; Installation of Gas Fired Hot Water Boilers 60kW to 2MW.
- CP 341; Water Supply.
- British Gas Publications:
  - IM2; Purging Procedures on Non-domestic Gas Installations.
  - IM5; Soundness Testing Procedures for Industrial and Commercial Gas Installations.
  - IM11; Flues for Commercial and Industrial Gas Fired Boilers and Air Heaters.
- Model Water Byelaws.

This appliance must be installed externally in open air (without a flue) or indoors (with a suitable flue system) in a room separated from living rooms and provided with appropriate ventilation direct to the outside.

The appliance must be used only in accordance with these instructions. Incorrect use is dangerous and invalidates all warranties and Certification.


#### Conversion Instructions.

The heater is supplied in two versions, one for use with Natural Gas, G20 at 20 mbar inlet pressure, the other for Propane, G31 at 37 mbar. If it is necessary to convert the heater for use on the other gas the appropriate conversion kit must be purchased and fitted using the instructions provided.

**NOTE:** *The heater should not be located in an area where possible water leakage will result in damage to the area adjacent to the appliance or to the structure. When such locations cannot be avoided, it is recommended that a suitable drain pan, adequately drained, be installed under the appliance. The pan must not restrict combustion air flow.*

#### BASE INSTALLATION

Heater must be mounted on a level base, such as cement slab, cement blocks or other non-combustible surface. An alternative method for providing a base for combustible floors is illustrated below. Heaters must **not** be installed on carpeting.



Hollow concrete cinder block, align holes and leave ends open. Alternative method for providing a non-combustible base.

## CLEARANCES

### ALL HEATERS

For clearances from combustible surfaces, see the chart below.

CLEARANCE FROM COMBUSTIBLE MATERIAL (mm)					
Plant Room Installation					
Model	Top	Back	Right	Left	Front
<b>055</b>	900	50	150	150	Clear
<b>105</b>	900	50	150	150	Clear
<b>155</b>	1050	300	150	300	Clear
<b>185-405</b>	750	150	300	150	Clear
Outdoor Installation					
Model	Top	Back	Right	Left	Front
<b>055</b>	Clear	50	150	150	Clear
<b>105</b>	Clear	50	150	150	Clear
<b>155</b>	Clear	300	150	150	Clear
<b>185-405</b>	Clear	150	150	150	Clear


For servicing, provide at least 600mm (24") in front of the heater for burner tray removal, and at least 450mm (18") on water connection side of the heater to inspect and delime the heat exchanger.

Heaters must not be installed under an overhang of less than 1.0m (3 feet) from the top of the heater. Three (3) sides must be open in the area under the overhang. Roof water drainage must be diverted away from the heaters installed under overhangs with the use of gutters:

The point from where the flue products exit the heater must be a minimum of 1.25m (4 feet ) below, four (4) feet horizontally from or 0.3m (1 foot) above any door, window or gravity inlet to a building. The top surface of the heater shall be at least 1.0m (3 feet) above any forced air inlet, or intake ducts located within 3.0m (10 feet) horizontally.

### HIGH WIND CONDITIONS (OUTDOOR HEATERS ONLY)

In areas where high winds are frequent, it may be necessary to locate the heater a minimum of 1.0 m from high vertical walls, or install a wind break so the heater is not in direct wind current.




clear.tif

## OUTDOOR HEATERS

These heaters are certified by Advantica for outdoor installation, when equipped with the approved tops designated for outdoor use.

**WARNING:** The heater shall not be located in an area where water sprinklers, or other devices, may cause water to spray through the cabinet louvres and into the heater. This could cause heavy internal rusting or damage some electrical components, and this would void the warranty.

It is recommended that the casing is cleaned and sprayed with WD40 or similar liquid, and exposed threads on the manifolds are lightly coated in grease, after assembly.




## FLUE CONNECTIONS AND DIMENSIONS

### 055 Models


FLUE TERMINAL (Outdoor) Stackless Top Illustration

- 1: Remove the (8) screws which fasten jacket top to heater.
- 2: Line up top vent opening over heater vent opening
- 3: Lower outdoor top onto unit lining up slots in outdoor top with screw holes in jacket top.
- 4: Reinstall (8) screws to secure jacket top and outdoor top to unit.



### 105 & 155 Models


FLUE TERMINAL (Outdoor) Stackless Top Illustration




### 185, 265 & 405 Models

FLUE TERMINAL (Outdoor) Stackless Top Illustration

1. Insert tabs into keyhole (4 places).



2. Snap tabs into keyholes so as not to pull out.




## INDOOR HEATER

The design is also certified by Advantica for indoor installation when fitted with the appropriate draught diverter and a suitable flue system to outside. Note that the heater must be in a room separated from living rooms and provided with appropriate ventilation direct to the outside.

### 055 Models

#### FLUE TERMINAL (Indoor) Draught Diverter Illustration


Locate and assemble as shown. Secure with screws supplied in envelope inside carton.



### 105 & 155 Models

#### FLUE TERMINAL (Indoor) Draught Diverter Illustration


Locate and assemble as shown. Secure with screws supplied in envelope inside carton.



### 185, 265 & 405 Models

#### FLUE TERMINAL (Indoor) Draught Diverter Illustration


1. Remove the louvred jacket top by removing four (4) No.10 flat head screws.
2. If originally installed, remove "Pagoda" top from the louvred jacket top.
3. Place the inner stack adapter panel over the flue collector inside the heater. Make sure the flanged side of the flue opening is up.
4. Turn the stack (diverter) upside down and set it down bottom side up.
5. Turn the jacket top panel (removed in step 1) down and place it through the stack.
6. Attach the three (3) mounting brackets to the stack using the screws provided and the holes that are pre-drilled in the stack. **Make sure the brackets are positioned with the flange near the top side of the stack (see illustration below).**  
*Caution must be taken not to over tighten and strip the screw threads.*
7. Turn the assembled stack and jacket top, right side up. The jacket top will be trapped between the brackets and the top of the stack. Place the stack over the inner adapter panel flanged hole and lower the louvred jacket top panel back into its original position. Reinstall the four (4) No.10 flat head screws removed in step 1 above.




405term.tif

SPECIFICATIONS & DIMENSIONS 055 - 105 - 155					
MODEL	FLUE DIA mm (in.)	CONNECTIONS		SHIPPING WEIGHT kg (lbs)	
		GAS	WATER	APPLIANCE	DIVERTER
055	100 (4)	½"	1½" NPT	31.8	(70) 2.3 (5)
105	127 (5)	½"	1½" NPT	48	(105) 3.5 (8)
155	152 (6)	¾"	2" NPT	62	(135) 3.5 (8)

### DIMENSIONS - 055 Model Only




### DIMENSIONS - 105 Model Only






## DIMENSIONS - 155 Model Only



## SPECIFICATIONS & DIMENSIONS 185 - 265 - 405

MODEL	WIDTH (A) mm (in.)	FLUE DIA (B) mm (in.)	CONNECTIONS		SHIPPING WEIGHT	
			GAS	WATER	kg (lbs)	
					APPLIANCE	DIVERTER
<b>185</b>	464 (18 1/4)	150 (6)	3/4"	2" NPT	86.8 (191)	5.5 (12)
<b>265</b>	568 (22 3/8)	175 (7)	3/4"	2" PLASTIC	97 (214)	7 (15)
<b>405</b>	743 (29 1/4)	230 (9)	3/4"	2" PLASTIC	115 (253)	9 (20)



## VENTILATION REQUIREMENTS

The heater must have both ventilation and combustion air. Safe and efficient operation of the heater is vitally dependant upon a good supply of fresh air to the room in which the appliance is installed. Minimum requirements for net free air supply openings direct to outside air at both high and low level are detailed in the table at the bottom of this page.

Position grilles to avoid the risk of accidental blockage or flooding. Further guidance is given in BS6644.

**CAUTION:** Combustion air must not be contaminated by corrosive chemical fumes which can damage the heater and void the warranty.

**NOTE:** The design is also certified by Advatica for indoor installation when fitted with appropriate manufacturer's draught diverter and a suitable flue system to outside. The heater must be in a room separated from living rooms and provided with appropriate ventilation direct to outside. It must not be installed in a cupboard or compartment which is directly connected to a living space.

## FLUE SYSTEM

### WARNING:

Indoor boilers require a draught diverter that must be connected to a flue pipe and properly flued to the outside. Failure to follow this procedure can cause fire or fatal carbon monoxide poisoning.

To ensure safe and satisfactory operation of the heater, the flue system must be capable of the complete evacuation of flue products at all times. The effective height of the flue terminal above the draught diverter must ensure sufficient buoyancy to overcome the resistance of the bends and horizontal runs of the flue pipe. The number of bends and length of horizontal run must be kept to a minimum to reduce resistance.

The chimney must terminate in a downdraught free zone.

Compliance with the recommendations made in BS 6644; British Gas publication IM11 "Flues for Commercial and Industrial Gas fired boilers and air heaters" and the "Third Edition of the 1956 Clean Air Act memorandum" should be strictly observed where applicable.


The flue/chimney design should avoid the formation of excessive quantities of condensate and for this reason it is recommended that all chimneys are suitably insulated and lined.

The draught diverter supplied with the heater must be used.

Drain points should be fitted at the bottom of all vertical flue sections. Drain pipes must be a minimum of 25mm (1 in) internal diameter and manufactured from acid condensate resistant material (eg stainless steel) and positioned so that pipe runs and discharge points are not subject to the effects of frost and that flue gases cannot leak into the room.

Any terminal fitted must be of a type acceptable to British Gas plc.

As part of commissioning, the flue must be satisfactory when tested for flue flow and spillage as detailed in BS5440 Part 1.



Flue.pcx

Model	Input (kW)	Plant Room (cm <sup>2</sup> )			
		Inside		Outside	
		High	Low	High	Low
055	13	117	234	59	117
105	27	243	486	122	243
155	39	351	702	176	351
185	50	450	900	225	450
265	72	-	-	297	600
405	108	-	-	378	756

ref. BS5440 for models under 60kW  
ref. BS6644 for models over 60kW

## GAS SUPPLY CONNECTIONS

Gas piping must have a manual shut-off valve located outside the heater jacket. All gas piping should be tested after installation in accordance with local codes.

**CAUTION:** The heater and its manual shut off valve must be disconnected from the gas supply during any pressure testing of that system at test pressures in excess of 150mbar (2.2psi). Dissipate test pressure in the gas supply line before reconnecting the heater and its manual shut off valve to gas supply line. **FAILURE TO FOLLOW THIS PROCEDURE MAY DAMAGE THE GAS VALVE. OVER PRESSURED GAS VALVES ARE NOT COVERED BY WARRANTY.** The heater and its gas connections shall be leak tested before placing the appliance in operation. Use soapy water for leak test. **DO NOT** use open flame.

**NOTE:** Do not use PTFE tape on the gas line pipe thread. A flexible sealant is recommended. Models 055 and 105 are fitted with a ½" BSP gascock, all others have a ¾" gascock.

A minimum of 20 mbar (8") WG and a maximum of 22 mbar (8¾") W.G.upstream pressure under load, and no load conditions are provided for natural gas or a minimum of 37mbar (14¾") W.G.and a maximum of 45 mbar (18") W.G for propane gas.


## GAS PRESSURE

For LPG Heaters the gas pressure is regulated by the injectors fitted in the factory. There is no adjustment.

For NG Heaters the regulator on the gas valve is factory set. If adjustment is required, remove the cap and turn the adjustment screw clockwise to increase and counter-clockwise to decrease the burner pressure.

## Honeywell Gas Valve

Burner Pressure adjustment



## PIPE SIZING FOR GAS CONNECTIONS

### MAXIMUM EQUIVALENT PIPE LENGTH METRES

N - NATURAL GAS @ 1.0 mbar PRESSURE DROP							
P - L.P.G. @ 2.5 mbar				PRESSURE DROP			
	10mm		15mm		22mm		28mm
MODEL	N	P	N	P	N	P	N
055		6	12	15			
105			3	5	20		
155					10.5	>24	36
185					8	>24	29
265					4.5	18	14.5
405						8.5	7

**PLUMBING FOR WATER CONNECTIONS**  
**LEFT SIDE WATER CONNECTION CONVERSION**  
***185, 265 & 405 Models Only***

**There are two ways of achieving the connection conversion. Removal and turning of the heat exchanger or, swapping of the headers.**

**Generally swapping headers is easier and this process is described here.**

1. Remove the right and left side access panels (Fig.1 & 2)
2. Withdraw the temperature and overheat sensors from their pockets (beware of the heatsink compound) and disconnect the connections to the pressure switch and the overheat thermostat.
3. Re-route the sensors and cables to the other side.
4. Remove the 12 bolts holding the Headers to their respective tubesheets.
5. Clean the mating surfaces for the header gaskets and the gaskets themselves.  
(NB. Use only silicone grease as a lubricant)
6. Fit the headers on their new sides ensuring they are square and correctly compressing the gasket.
7. Refit the sensors and connectors to the safety devices.
8. Re-commission and check for leaks.
9. Replace the side access panels.





Fig. 1

Fig. 2



This page is intentionally left blank

## CONNECTIONS

### All Models

#### LOCATION


The heater requires water flow and pressure to operate properly. It must therefore be installed downstream of the discharge side of the filter and pump. A typical installation is plumbed as follows:

1. The Pump outlet is plumbed to the inlet of the Filter.
2. The outlet side of the Filter is then plumbed to the inlet of the Heater.
3. The outlet of the Heater is plumbed to the return line to the pool or spa. The Pump, Filter and Heater are plumbed in series.



Plumbing from the heater back to the pool must not have any valves or restriction that could prevent flow when the pump is operating.

Use the pressure loss chart below to specify a suitable pump.

**PRESSURE LOSS CHART 055 / 105 / 155 MODEL ONLY**



**PRESSURE LOSS CHART 185 / 265 / 405 MODELS ONLY**



Heater must be located so that any water leaks will not damage the structure of adjacent area. High temperature 2" plastic pipe (CPVC) may be threaded directly into the Cast Iron header flanges. This is not the same as the Schedule 80 PVC pipe which is also coloured grey. PVC may be used immediately after the CPVC adapters.

**NOTE:** If operating pressure above 2 bar (30psi) are encountered then connection pipes must either be screwed into the flange or suitably anchored.

**CAUTION:** NEVER install PVC directly into Cast Iron header flanges.

#### FLOW RATES

MODEL	PIPE SIZE	MINIMUM/min. Litres (Gals)	MAXIMUM/min. Litres (Gals)
055	1-1/4"-1-1/2"	77 (17)	225 (50)
105	1-1/4"-1-1/2"	77 (17)	430 (95)
155	1-1/4"-1-1/2" -2"	77 (17)	430 (95)
185	1-1/4"-1-1/2" -2"	77 (17)	470 (104)
265	1-1/4"-1-1/2" -2"	95 (21)	470 (104)
405	1-1/4"-1-1/2" -2"	150 (33)	470 (104)

\*When flow rates exceed maximum an external auxiliary bypass valve is required. See external bypass valve section for details.

#### COMPANION FLANGE CONNECTIONS


**DO NOT** use petroleum base assembly fluids (such as Petroleum Jelly or lubricating oil). If assembly lube is required, use a silicone grease.

#### 055 Model Only

The inlet/outlet header flange accepts a 1½" copper tube or 1¼" galvanized pipe as a slip connection directly into the manifold. The flange is also threaded for 1½" pipe thread.




### 055 Models Only




### 105 Model Only

The 105 accepts direct connection to 1½" plastic pipe using the adapters provided.



### 155 Model Only



There are two sets of flange gaskets supplied with your heater. Use the appropriate gaskets for all your heater connections. Discard unused set.  
**DESIGN 1:** Accepts 1½" copper tube or 1¼" galvanized pipe as a slip connection.  
**DESIGN 2:** Accepts 2" copper tube as a slip connection. The flange is threaded for 2" screw in pipe connections. Also used with the 2" CPVC adapters.



### 185, 265 & 405 Models Only



Ensure the O rings are properly seated before tightening hand tight. They may be lubricated with silicone grease. Glue plastic pipe directly in to the unions.

### UNITHERM GOVERNOR OPERATION


#### **Does not apply to 105 Model**

The patented Unitherm Governor is a thermostatic mixing valve specifically designed to maintain constant heater internal temperature between 40.6 to 46.1°C despite continually changing flow rates from the filter and changing pool temperatures. This narrow range is needed to prevent damaging condensation on the burners which will occur if the heater runs for any length of time below 37.8°C. It is also needed to inhibit scale formation in the tubes by maintaining temperatures well below accelerated scaling temperatures.

### INTERNAL AUTOMATIC BY-PASS VALVE


#### **Does not apply to 055 Model**

In addition to the Unitherm Governor, a built-in automatic by-pass valve is provided in the in/out header. While the Unitherm Governor responds to the changes in water temperature in the heater, the internal by-pass valve automatically responds to changes in water pressure in the piping system. Proper amount of water flow is maintained through the heater under varying pressures dictated by the conditions of the pump and filter.



## EXTERNAL AUXILIARY BYPASS VALVE (Where Required)

An auxiliary bypass valve should be used when flow rates exceed those shown in the table in the 'Connections' section on p18. (usually a high performance pump size larger than two HP will exceed this flow rate). This valve is required to complement the function of the automatic bypass valve, particularly when starting the heater in winter or early spring when the spa or pool temperature is down below 10°C. It also serves to eliminate needless pressure drop through the heater and accompanying reduction in the flow rate to the spa jets, etc.




## AUXILIARY BYPASS VALVE ADJUSTMENT

To set bypass: With clean filter, adjustment is made by feeling the inlet and outlet pipes at the heater. Outlet pipes should be slightly warmer than inlet and comfortable to the touch. If pipe is hot, close bypass; if cold, open bypass.

## ELECTRICAL WIRING

**NOTE:** If it is necessary to replace any of the original wiring, it must be replaced with 105° C wire or its equivalent, except all black wire which must be replaced with 150° C wire or its equivalent.

### INTERNAL WIRING



mainsin.tif

**NOTE:** Heaters are factory wired for 230V power supply.

**NOTE:** 22mm Dia. holes not utilized on jacket and control box can be used for fireman switch or auxiliary control interface wiring.

The Electronic Ignition Device automatically lights the pilot and main burners upon a call for the heat. The heater is supplied with a transformer for 230V mains input.

### NOTE:

Heater is equipped with an electronic ignition device with a 100% safety lockout feature. If the heater fails to start or lockout, reset the ignition device by interrupting the power to the heater for 10 seconds.

**Caution:** If service replacement of the electronic ignition device is required, replace only with the ignition component supplied as a required spare.

Abbey Ignition Device.



Wiring external to the appliance must be in accordance with the IEE Wiring Regulations and any local regulations which apply.

A 3 pin unswitched shuttered socket outlet, fused at 3A must be provided near to the heater, this should serve only the heater together with its controls and pumps.


Wiring should be 3 core PVC insulated (minimum,) not less than 24 x 0.2mm. All fuses must be ASTA approved to BS1362.

Connect the power supply as shown above. Ensure that the cable is clamped in the cable clamp. The wires must be such that the current carrying conductors become taut before the earth conductor in the event of the cable clamp not gripping the cable adequately.

**NOTE:** Input power to the heater (220V) should be supplied from the load (Pump) side of time clock or switch. Connecting heater to continuous power source will allow "Fail" indications (service and pressure switch) when pump is not operating.

# WIRING DIAGRAM 055-105-155 MODELS ONLY


## ABBAY IGNITION DEVICE



30/09/04

# WIRING DIAGRAM 185-265-405 MODELS ONLY


## ABBEY IGNITION DEVICE




## SECTION 3 / SERVICING INSTRUCTIONS

### GENERAL LOCATION OF CONTROLS


#### 055 MODEL




#### 105 MODEL



#### 155 MODEL



**185-265-405 MODEL**




**155 Model**

**CONTROL PANEL REMOVAL**

1. Remove lower door.
2. Remove (2) screws from bottom flange of control panel.
3. Slide down control panel to clear jacket top panel.
4. Rotate control panel down until panel stops. Do not force.

**NOTE:** Caution must be taken not to damage controls or wiring.




**185,265 & 405 Models**

**CONTROL PANEL REMOVAL**


1. Remove (4) screws from sides of control panel.
2. Rotate control panel down until panel stops. Do not force.

**NOTE:** Caution must be taken not to damage controls or wiring.






## 185 265 and 405 Models



### Summary of Controls (Left to Right)

**ON/OFF Switch** - Turns the Heater On and Off and resets the Ignition Control if locked out.

 **Lock/Unlock Button** - If it is pressed for 2 seconds it locks the Set Temperature so the Pool Temperature Knob is inoperative. To unlock, press again for 2 seconds. With a short press the Set temperature is displayed. It will flash if the Lock is ON.

**Pool Temperature Display** - This normally shows the Pool Temperature but also show the Setting Temperature when the Pool Temperature Control Knob is moved. A Setting Dot is displayed whilst it is adjusted. The Display is also used for commissioning and diagnostic purposes.

(Page 34)

### Pool Demand LED - Green

**Off** - There is no Pool Heating demand, pool heating is off.

**On** - There is Pool Heating Demand and the Pool is not up to temperature.


**Flashing** - The Pool Heating Demand is met, the pool is up to temperature.

### Pool Temperature Control Knob

16°C to 32°C or 41°C (60°F to 90°F or 106°F)

(Maximum is changed in Setup Mode, see Page 34)

Rotate clockwise to increase the Pool Temperature. The Setting Temperature is shown whilst rotating and for 3 seconds after.

To lock the required Temperature Setting see  **Lock/Unlock Button**.

### Pool Filter Blocked - Yellow

**On** - If the pump is running and there is insufficient pressure, possibly due to a blocked Pool Filter. The Heater will not run.

### Overheat - Red

**On** - This indicates the Heater has overheated and shutdown. Reset. If this persists this should be investigated by a Service Engineer.

### Overheat Reset (not on front panel)


If the Overheat Indicator has lit the Heater will not work until the thermostat has been reset. Wait until the Heater is cool then remove the door and locate the Overheat Thermostat mounted on its bracket. Press its centre and it will click.

The Red Overheat indicator will go out and the Heater can now run.

## 055, 105 & 155 Models

The pool or spa water temperature is controlled by the pool heater thermostat on the front panel of the heater. The control centre contains an On/Off switch and one Temperature Control Knob. The switch functions as a means for turning the heater on or off, however for longer periods of isolation the Heater should be switched off at its Mains supply.

The Thermostat is fitted with a means of limiting the upper temperature limit below the maximum level. The knob stop adjustment ring illustrated below is adjustable by loosening the set screw, rotating the knobstop ring to the desired location and retightening the set screw.



## All Models

### PRESSURE SWITCH

The pressure switch, or heater actuator, ensures that the heater operates only when the filter pump is in operation.


It is factory set at 0.12 bar (1.75 PSI) for deck level installations. When the heater is located below the level of the spa or pool, it may be necessary to reset the pressure switch to compensate for the no-flow static head.

If it is necessary to reset the pressure switch, we recommend the following procedure:


## All Models

### PRESSURE SWITCH ADJUSTMENT

1. With pump and heater on, turn adjustment knob (clockwise) until a click is heard from the gas valve.
2. Turn adjustment knob (**counter clockwise**) 1/4 turn.
3. Turn pump off and on several times. Heater should shut off immediately. If it does not, repeat steps above until proper adjustments is made.



### PRESSURE SWITCH ADJUSTMENT RANGE




**NOTE:** If heater is installed outside of the limits shown, a flow switch must be used in place of the pressure switch when mounted and wired adjacent to the heater.

### TWO SPEED PUMPS

In some cases, the flow on the low speed is insufficient to operate the heater. This is apparent when the pressure switch cannot be further adjusted or if the heater makes banging noises. In these cases, the pump must be run at high speed when heating the water.


**CAUTION:** Do not operate the heater without the function of a properly adjusted pressure switch or flow switch.

### FLAME ROLL-OUT SAFETY SWITCH



The heater is equipped with a thermal cutoff device to prevent flame roll-out in the event that the heat exchanger becomes blocked. This is a "Single-use" type fusible link or thermal fuse, that must be replaced when disabled by an over temperature condition, caused by excessive restriction in the heat exchanger flue passage.

### HIGH LIMITS



The heater is equipped with one manual reset over-heat thermostat located in the return header, set to open at approx. 100°C. the other is the Automatic Gas Shut-off limit, set to open at 57°C and located in the Inlet/Outlet header.

**NOTE:** An erratic high limit is often characteristic of internal heat exchanger problem, i.e. scale buildup, defective bypass. Refer to troubleshooting sections.

### 055, 105 & 155 Models

#### HIGH LIMIT & MANUAL RESET HIGH LIMIT THERMOSTAT REMOVAL

Disconnect top portion of unit. (See heat exchanger removal procedure steps 1 thru 7 and step 10).

1. Remove Jacket Top, Flue Collector and Baffle.
2. Remove defective high limit and replace with new high limit.

3. To remove the manual reset high limit, follow the procedure for the high limit thermostat but in addition, disconnect the electrical connections and release its mounting bracket from the side panel by removing the M4 nut at the front of the bracket. The thermostat can then be removed from its bracket. Ensure thermostat phial is correctly located in its pocket.
4. Reverse above procedure to reinstall.

### **185, 265 & 405 Models**

#### **MANUAL RESET HIGH LIMIT REMOVAL**

1. Shut off main electrical power switch to heater.
2. Remove inspection panels.
3. Disconnect electrical connections from thermostat.
4. Remove defective high limit and replace with a new high limit. Secure bulb in pocket with chip provided.
5. Reverse above procedure to reinstall.

#### **HIGH LIMIT REMOVAL (A.G.S.)**

1. Shut off main electrical power switch to heater.
2. Remove inspection panels.
3. Drain heater.
4. Remove defective high limit and replace with a new high limit.
5. Reverse above procedure to reinstall.

### **All Models**

#### **PILOT SAFETY IGNITION**

The heater employs a pilot safety which closes the main gas valve within 8/10ths of a second whenever the pilot flame is interrupted. Pilot flame is automatically lit when the device is powered. Unit performs its own safety check and opens the main valve only after the pilot is proven to be lit.

#### **BURNER DRAWER REMOVAL**

1. Shut off main electrical power switch to heater.
2. Shut off gas upstream of heater.
3. Remove front door.
4. Disconnect gas line from gas valve.
5. Remove (2) screws that mount burner tray to unit.
6. Disconnect wires that terminate at gas valve.
7. Slide out burner tray.
8. Reverse above procedure to re-install.

**NOTE:-IMPORTANT Reconnect Earth Connection**

### **055, 105 & 155 Models**

#### **GAS VALVE REMOVAL**

1. Remove burner tray. (See burner drawer removal procedure).
2. Disconnect pilot tubing from gas valve.
3. Remove gas valve with manifold from burner tray.
4. Remove manifold from gas valve.
5. Reverse above procedure to re-install.

### **185, 265 & 405 Models**

#### **GAS VALVE REMOVAL**

1. Shut off gas supply to the heater. Remove gas piping to gas valve inlet.
2. Disconnect wires, pilot tubing and bleed line, if required.
3. Turn vertical gas pipe from manifold slightly and unscrew gas valve.
4. Reverse above procedure to re-install.

### **All Models**

#### **MAIN BURNER AND INJECTOR REMOVAL**

1. Remove burner drawer. See burner drawer removal procedure.
2. Remove screws and burner hold down bracket.

**NOTE:** *If the heat exchanger is sooted badly, the burner hold down bracket and spacer can become distorted from direct flame impingement and this usually necessitates replacement of these parts.*

3. Lift burners from slotted spacers and slide from orifices. Clean with a wire brush.
4. Orifices usually do not need to be replaced. To clean, run either copper wire or a drill shank through orifice. Do not enlarge hole. To remove orifice, use a socket wrench and remove from manifold. **DO NOT** overtighten when reinstalling.

### **055, 105 & 155 Models**

#### **PILOT REMOVAL AND CLEANING**

1. Remove burner drawer. (See burner drawer removal procedure).
2. Disconnect pilot tubing, disconnect wires from gas valve.
3. Disconnect pilot bracket from burner shield.
4. Remove pilot from bracket.
5. Remove pilot orifice, and clean with wire or small brush. **CAUTION! DO NOT** enlarge hole in pilot orifice.
6. Reverse above procedure to re-install.

### 185, 265 & 405 Models

#### PILOT REMOVAL AND CLEANING

1. Disconnect pilot tubing, and wires from gas valve.
2. Remove pilot assembly from burner tray.
3. Remove pilot from bracket.
4. Remove pilot injector and clean with wire or small brush. **CAUTION!** Do not enlarge hole in pilot orifice.
5. Reverse above procedure to re-install.

#### HEAT EXCHANGER REMOVAL

1. Shut water, gas and electricity off, close valves and relieve pressure, remove relief valve. Remove side inspection panels.
2. Remove top holding screws.
3. Remove draft diverter, lift and remove top and flue collector. Remove inspection panels.
4. Loosen bolts and disconnect flange nuts on inlet-outlet header, loosen union(s) at gas pipe and slide boiler away from piping until studs clear the header.
5. Lift heat exchanger straight up using caution not to damage refractory.
6. Reverse above procedure to reinstall.

### 055, 105 & 155 Models


#### HEAT EXCHANGER REMOVAL

1. Shut water, gas, and electricity off, close valves and relieve pressure.
2. Drain heat exchanger.
3. Loosen and remove flange bolts.
4. Remove flange and inlet/outlet pipes from the header.
5. Remove outdoor stackless top or indoor stack top from unit.
6. Remove jacket top, flue collector, and baffles.
7. Remove upper front jacket panel, and disconnect wires at toggle switch.
8. Remove capillary bulb from inlet/outlet header.
9. Disconnect press switch tube from return header.
10. Disconnect hi-limit wire from thermostat, and pressure switch. Remove overheat thermostat capillary & phial.
11. Lift heat exchanger straight up from combustion chamber, using caution not to damage refractory.
12. Reverse above procedure to re-install.

### All Models

#### CONTROL IMMERSION WELL REPLACEMENT

1. Shut water off to heater and drain heat exchanger.
2. Remove jacket top panel.
3. Remove old control well with bushing and sleeve, with 7/8" wrench or socket.
4. Slip "o" ring gasket over control well and install in header.




#### TUBE CLEANING PROCEDURE (Typical)

Establish a regular inspection schedule, frequency depending on local water condition and severity of service. Do not let the tubes clog up solidly. Clean out deposits over 1.5 mm in thickness.

The heater must be cleaned from the rear as shown. It is preferable, however, to remove the heat exchanger and the in/out header for better visibility through the tubes and to be sure the ground-up lime dust does not get into the system, Note that you do not remove the top panel or the heat exchanger, generally.

After reaming, mount the wire brush in place of the auger and clean out debris remaining in the tubes. Another method is to remove the heat exchanger, ream tubes and immerse heat exchanger in non-inhibited de-scale solvent.



## All Models

### DESOOTING PROCEDURE

**CAUTION:** SOOT IS COMBUSTIBLE. EXERCISE EXTREME CARE. NEVER USE A WIRE BRUSH.

Soot can clog areas between fins and cause eventual tube failure. Any sign of soot at the base of the burners or around the outer jacket indicates a need for cleaning.


1. Disconnect top portion of unit. (See heat exchanger removal procedure steps 1 through 6).
2. Remove burner tray (See burner drawer removal procedure.)
3. Take a garden hose and wash heat exchanger, making sure soot is removed completely from between fins. Avoid excessive water against refractory.

**NOTE:** DO NOT WIRE BRUSH.

## 055, 155, 185, 265 & 405 Models

### UNITHERM GOVERNOR (U.G.) REPLACEMENT

1. Shut water, gas and electricity off, close valves and relieve pressure.
2. Drain heat exchanger.
3. Remove retainer located under outlet pipe connection.
4. Remove spring and replace old U.G. with a new U.G.
5. Reverse above procedure to reinstall.




To test the operation of the UniTherm Governor, place in hot water (over 43°C) and watch for movement against spring. If there is no movement, replace unit.

## 055, 105 & 155 Models

### COMBUSTION CHAMBER REMOVAL

1. Remove heat exchanger (See heat exchanger removal procedure).
2. Lift up and remove front and rear refractory shield.
3. Remove refractory panels.
4. Reverse above procedure to re-install.




Refractory Panels Top View

## 185, 265 & 405 Models


### COMBUSTION CHAMBER REMOVAL

To remove combustion chamber, you must first have removed the heat exchanger. Unbolt metal combustion chamber retainer from top and remove combustion chamber panels individually.



ref265.dwg

Refractory Panels Top View





## SECTION 4 / TROUBLE SHOOTING GUIDE

**IMPORTANT NOTICE:** These instructions are primarily intended for the use of qualified personnel specifically trained and experienced in the installation of this type of heating equipment and related system components. Installation and service personnel must be Corgi Registered. Persons not qualified shall not attempt to install this equipment nor attempt repairs according to these instructions.

### ***All Models***

#### **MECHANICAL ( FOR QUALIFIED SERVICE PERSONNEL ONLY )**

<u>PROBLEM</u>	<u>CAUSE</u>	<u>SOLUTION</u>
Harmonics, or whining noise.	U.G. inoperative.....	Check movement by putting into hot water (43°C or higher). If no movement, replace.
	*Debris or restriction in system...	Locate the restriction and remove. Flush system and clean.
	*Debris in gas line.....	Remove debris or blow out gas line.
	Low flow.....	Scale forming in heat exchanger - clean heat exchanger and check pool pH and total alkalinity.
Heater going on and off continuously.	Dirty filter.....	Backwash filter.
	Low water level in pool.....	Raise water level.
	External bypass setting out of adjustment.....	Adjust bypass
	*Pressure switch out of adjustment.....	Adjust pressure switch
Liming or scale forming on heat exchanger.	Pool water.....	Recommended pH should be between 7.4 and 7.8 total alkalinity 100-150 PPM maximum. Hardness 150-400 PPM maximum.
Sooting	High flow rates.....	Reduce by adding manual bypass valve and adjust by putting thermometer in header (1/4" NPT) drain opening. Set bypass so thermometer reads between 40°C and 43°C.
	U.G. Inoperative.....	Check movement by putting in hot water (43°C or higher). If no movement, replace.
	*Air starvation.....	Refer to installation instructions.
	*Improper venting.....	Follow recommended installation instructions.
	*Insects or debris clogging burner intake ports.....	Clean burners.

(\* Usually occurs on initial start-up.)




<u>PROBLEM</u>	<u>CAUSE</u>	<u>SOLUTION</u>
Pilot outage.	Low gas pressure.....	Adjust gas pressure.
	Restricted pilot.....	Clean pilot.
	Weak pilot generator.....	Replace pilot.
	Faulty Detection Electrode or PCB	
Yellow lazy flame	Low gas pressure.....	Adjust gas pressure.
	*Insects or debris clogging burner intake ports.....	Clean burners.
Inner & Outer panels very hot (paint blistered - thermal fuse in transformer failed)	*Gaps in corner of refractory Broken refractory caused by shipping damage or improper combustion.....	Replace or re-align refractory to seal gaps. Replace transformer.
	Excessive sooting of heat exchanger.....	Determine cause of sooting & correct.
Takes long time to heat pool or spa.	Calculate temperature in °/hr.....	Heat rise (°/hr.)= $\frac{\text{Heater Output}}{\text{Pool gallonage} \times 8.33}$ or refer to heater sizing chart. This does not take into account heat loss due to weather.
	Filter not running long enough.....	Reset time clock.
	Dirty filter.....	Clean filter.
	Gas line or meter undersized.....	Refer to installation instructions.
Liming	Bypassing too much water.....	Inspect bypass for movement, if no movement, replace.
	U.G. not functioning.....	Replace if no movement when heated.
Leaking at well.	Overacid.....	Replace well and maintain water chemistry properly.
Leaking at heat exchanger.	Overacid.....	Replace heat exchanger and maintain chemistry properly.
Gasket brittle and leaking - (overheated).	Heater running after pump shuts off.....	See pressure switch adjustment.
	Refractory damage.....	Replace refractory.
	Sooted heater.....	Determine cause of sooting and correct.

(\* Usually occurs on initial start-up.)

**055, 105 & 155 Models**  
ELECTRICAL TROUBLESHOOTING

**WARNING**  
HIGH VOLTAGE  
For qualified Technicians ONLY

**\*NOTE:** This heater is equipped with an ignition module that shuts off pilot gas if pilot fails to light after the third attempt. This is identified by the green LED flashing on the ignition module. To reset, interrupt power to heater.



## ELECTRICAL TROUBLESHOOTING

**055, 105 & 155 Models** If the pool/spa water is too cold, troubleshoot the system as follows:

Check voltage at 24 V terminals.

**VOLTAGE BETWEEN 21.5-28.5 V.**

Set control to max. temperature. After 2-3 cycles, check water temperature.

**TEMPERATURE BELOW 40°C**

Disconnect sensor leads from circuit board. Measure sensor resistance with ohmmeter.

**RESISTANCE 1-14k OHMS.**

Check water temperature; estimate expected sensor resistance from chart below.

**MEASURED AND ESTIMATED RESISTANCE MATCH WITHIN 20 PERCENT.**

Disconnect potentiometer leads from circuit board. Measure resistance with ohmmeter. If resistance is:  
*0-100 ohms at minimum setting;*  
*9k to 11k at maximum setting, replace circuit board.*

*Above 11k ohms but less than 15 k ohms, replace potentiometer.*

*Above 15k ohms, fix loose or broken wires; replace potentiometer if necessary. Reconnect all leads and check out system.*

**VOLTAGE OUTSIDE RANGE 21.5-28.5 V.**

Check transformer, 230 V supply, correct as necessary. If 230 V side of transformer is open circuit, check combustion chamber for heat leaks  
 Check 3 Amp fuse.

**TEMPERATURE 40°C-40.5° C.**

Control ok.

**RESISTANCE 0 OHMS (SHORT CIRCUIT)**

Check system for shorted wires or open circuits. Replace sensor if necessary.

**MEASURED AND ESTIMATED RESISTANCE DON'T MATCH.**

Replace sensor. Reconnect all leads and check out system.

**If the pool/spa/hot tub water is too hot, troubleshoot the system as follows:**

Check voltage at 24 V terminals.

**VOLTAGE BETWEEN 21.5-28.5 V.**

Set control to max. temperature. After 2-3 cycles, check water temperature.

**TEMPERATURE ABOVE 42°C**

Disconnect sensor leads from circuit board. Measure sensor resistance with ohmmeter.

**RESISTANCE 1-14k OHMS.**

Check water temperature; estimate expected sensor resistance from chart below.

**MEASURED AND ESTIMATED RESISTANCE MATCH WITHIN 20 PERCENT.**

Disconnect potentiometer leads from circuit board. Measure resistance with ohmmeter. If resistance is:

*0-100 ohms at minimum setting;*  
*9k to 11k at maximum setting,*  
*replace circuit board.*

*Above 11k ohms, replace potentiometer.*

*0 ohms (short circuit), replace potentiometer. Reconnect all leads and check out system.*

**VOLTAGE OUTSIDE RANGE 21.5-28.5 V.**

Check transformer, 230 V supply, correct as necessary. If 230 V side of transformer is open circuit, check combustion chamber for heat leaks  
 Check 3 Amp fuse.

**TEMPERATURE 40°C-40.5° C**

Control ok.

**RESISTANCE ABOVE 15k OHMS (OPEN CIRCUIT) OR SHORT CIRCUIT.**

Fix loose or broken wires. Replace sensor if necessary.

**MEASURED AND ESTIMATED RESISTANCE DON'T MATCH.**

Replace sensor. Reconnect all leads and check out system.

SENSOR RESISTANCE AT VARIOUS TEMPERATURES

Temperature (deg C)	16°C	20°C	21°C	25°C	30°C	31°C	35°C	40°C	41°C
(deg. F)	61	68	70	77	86	88	95	104	106
Resistance (k ohms)	14.9	12.5	11.9	10.0	8.1	7.7	6.5	5.3	5.1

## 185, 265 & 405 Models

### CONTROL FAULT DIAGNOSIS

Before commencing a diagnosis it is recommended that you familiarise yourself with the functions of the Controls. These are detailed in the **User's Operating Instructions Page 2**. The Control will diagnose and display most of its own faults.

#### Self Check

The Control does a full self check during power up. It also briefly lights all the LEDs and the Temperature Display so they can be checked for operation.

#### Pool Heating

The Control will try and fire the Heater provided that:

1. There is a Mains supply
2. The Heater is switched on
3. The Set temperature is above the Actual temperature.
4. The safety switches are all satisfied.

This will be indicated by the Green LED next to the display. On for firing, Off for no demand and Flashing for up to temperature.

#### Fault Indicators

There four LED indicators on the Control. Two on the Front Panel, Red for the Manual Overheat, Yellow for the Pressure Switch.

Two on the board behind the display, one for the Rollout or Thermal Fuse and one for the Hi-Limit Thermostat.

If any one of the safety switches open the associated LED will light. **NB** if more than one opens only one LED will light, the first in the chain.

#### Displayed Faults

The Control board detects and displays certain faults, the display alternates between the two codes.

Display	Reason	Action
Err / No	Control board fault	Power off then on. If not corrected, replace board
P / oc	Pool sensor Open Circuit	Check connections, if correct, replace sensor
P / cc	Pool sensor Short circuit	Check connections, if correct, replace sensor

#### Logs

The Control keeps a log of the number of times the Pressure Switch, Manual Overheat, Hi-Limit and Thermal Fuse (Rollout) fail. These can be examined and reset to zero in Setup Mode. The Temperature Displayed units and the Maximum Temperature can also be checked and viewed in Setup Mode.

#### Setup Mode


The following must be carried out within 5 seconds of turning on the Mains supply, this is when the display is fully illuminated.

Turn the Mains supply ON.

Press and hold the  Lock/Unlock Button until the display stops flashing.

The Control is now in Setup Mode.

The display will show additional data as the Pool Temperature Knob is rotated. **See Page 35**


The settings are altered by pressing the  Lock/Unlock Button.

To leave Setup Mode and retain the new settings, turn off the Mains supply for a few seconds at any time.

**Example.** To change the Display from Fahrenheit (°F) to Centigrade (°C)

Turn Mains OFF

Turn Mains ON


Press the  Lock/Unlock button within 5 seconds

Turn the Temperature Control Knob to position 1, the display will show °F

Press the  Lock/Unlock button to alter to °C.

Turn the Mains OFF

Turn the Mains ON




Setting		Factory Setting	Alternative	Display Indicator
1	Display units	° F = Fahrenheit	° C = Centigrade	° F or ° C
2	Maximum temperature	32 °C (90 °F)	41 °C ( 106 °F)	PL or SPA
3	Filter Pressure Log	Number of Operations	Resets to zero	Yellow Filter LED ON
4	Overheat Log	Number of Operations	Resets to zero	Red Overheat LED ON
5	Hi-Limit Log	Number of Operations	Resets to zero	Red PCB LED ON
6	Thermal Fuse Log	Number of Operations	Resets to zero	Red PCB LED ON
7	Version number	-	-	e.g. 003


## SECTION 5 REPLACEMENT PARTS LIST

### 055 & Easiheat Model



**NOTE:** To supply the correct part it is important that you state the model number, serial number and type of gas when applicable.



**Pilot ( Silver )**



**Pilot ( Black )**







<b>Key</b>	<b>Description - 055 Model</b>		<b>Part Code</b>
<b>B</b> 1-B 2-B 3-B	<b>BURNER TRAY</b> Burner Tray w/Gas Valve Natural Burner Tray w/Gas Valve Propane Burner Burner Injector Natural No.50 Burner Injector Propane No.57		- - 301210 350079 350083
<b>C</b> 2-C 3-C 4-C 6-C 7-C 8-C	<b>CONTROLS</b> High Limit 57°C (135°F) High Limit Manual Reset 102°C Thermostat Control (Solid State) Potentiometer Temperature Sensor Ignition Control, Abbey Ignition Control, Robertshaw		600889B M3029 600960 600961 600962 SPMB502/1 SPMB502
<b>G</b> 1-G 2-G	<b>GAS VALVE</b> Honeywell Gas Valve L.P.G. Softlight Adapter		M3265 M3694
<b>H</b> 1-H 2-H 3-H 4-H 5-H 6-H 7-H 8-H 9-H 10-H 11-H 12-H 13-H	<b>HEAT EXCHANGER</b> Heat Exchanger Assembly (Complete) Header / Tubed Kit Baffle Kit Unitherm Governor U.G. Cap U.G. Spring Drain Valve Sensor Well, High Limit Bulb Retainer Clip U.G Gasket Inlet/Outlet Flange Flange Gasket Bypass Baffle		063780 004695F 306790 600885 400734 850247 500719 M3028 300203 800276 350746 800013B 306079
<b>M</b> 1-M 2-M 3-M 4-M 5-M 6-M 7-M 8-M 9-M	<b>MISCELLANEOUS COMPONENTS</b> Pressure Switch Pressure Switch Tube Assembly Thermostat Knob Knob Stop Dial Plate Transformer Toggle Switch Wire Harness IID Thermal Fuse		650634 062212 800201 305138 M3060 M650531 650595 M3552 651360
<b>P</b> 1-P 2-P 3-P 4-P	<b>PILOT (Silver)</b> Pilot Natural/Propane Pilot Injector Natural Pilot Injector Propane Pilot Tube Hi-Tension Wire	<b>Part Code</b> 600799 M3274 601218 400013 651012	<b>PILOT (Black)</b> Pilot Natural/Propane Pilot Injector Natural Pilot Injector Propane Pilot Tube Hi-Tension Wire
<b>R</b> 1-R	<b>REFRACTORY</b> Refractory Kit	FT/RR LT/RR	M700348 M700349
<b>S</b> 1-S 2-S 3-S 4-S 5-S	<b>SHEETMETAL</b> Jacket Top Flue Collector Door Assembly Upper Jacket Control Panel Cable Clamp Bracket		305658 - M3299
<b>V</b> 1-V 2-V	<b>VENTING</b> Stackless Top (Outdoor) Drafhood (Indoor)		003709 003722

# REPLACEMENT PARTS LIST

**105 Model**




<b>Key</b>	<b>Description - 105 Model</b>			<b>Part Code</b>
<b>B</b>	<b>BURNER TRAY</b>			
1-B	Burner Tray w/Gas Valve Natural			-
2-B	Burner Tray w/Gas Valve Propane			-
3-B	Burner			301210
	Burner Orifice Natural	No.50		350079
	Burner Orifice Propane	No.59		350350
<b>C</b>	<b>CONTROLS</b>			
2-C	Automatic Reset Thermostat			601549
3-C	High Limit Manual Reset 102°C			M3029
4-C	Thermostat Control (Solid State)			600960
5-C	Potentiometer			600961
6-C	Temperature Sensor			600962
<b>G</b>	<b>GAS VALVE</b>			
1-G	Honeywell Gas Valve			M3265
2-G	L.P.G. Softlight Adapter			M3694
<b>H</b>	<b>HEAT EXCHANGER</b>			
1-H	Heat Exchanger Assembly (Complete)			064187
2-H	Inlet/Outlet Header			006887F
3-H	Return Header			351047
4-H	Tube Bundle			006889F
6-H	Baffle Kit			306255
7-H	Bolt Kit			006890F
8-H	Header Gasket			800014B
11-H	Bypass Valve			006716F
12-H	Bypass Spring			850252
	Drain Valve (not shown)			500719
14-H	Sensor Well, Pool Temperature			M3028
15-H	Well Retaining Clip			300203
16-H	Sensor Well, High Limit			M3028
<b>J</b>	<b>J BOX/CONTROL BOX</b>			
2-J	Ignition Control, Abbey			SPMB502/1
	Ignition Control, Robertshaw			SPMB502
3-J	Transformer 230V/24V			M650531
4-J	Toggle Switch			650595
<b>M</b>	<b>MISCELLANEOUS COMPONENTS</b>			
1-M	Pressure Switch			650634
2-M	Pressure Switch Tube Assembly			064685
3-M	Thermostat Knob			800201
4-M	Knob Stop			305138
5-M	DialPlate			M3060
8-M	Wire Harness			M3551
9-M	Thermal Fuse			651360
10-M	Elbow Adapter			M4031
<b>P</b>	<b>PILOT (Silver)</b>	<b>Part Code</b>		<b>PILOT (Black)</b>
1-P	Pilot Natural/Propane	600799	5-P	Pilot Natural/Propane
2-P	Pilot Injector Natural	M3274	6-P	Pilot Injector Natural
	Pilot Injector Propane	601218		Pilot Injector Propane
3-P	Pilot Tube	400013	7-P	Pilot Tube
4-P	Hi-Tension Wire	651012	8-P	Hi-Tension Wire
				M3699
				M3687
				M3688
				M3700
				M3695
<b>R</b>	<b>REFRACTORY</b>			
1-R	Refractory Kit	FT/RR LT/RT		700443
				700444
<b>S</b>	<b>SHEETMETAL</b>			
1-S	Jacket Top			306894
2-S	Flue Collector			064624
3-S	Door Assembly			
4-S	Upper Jacket Control Panel			
5-S	Control Panel			M306895
<b>V</b>	<b>VENTING</b>			
1-V	Stackless Top (Outdoor)			004898
2-V	Drafthood (Indoor)			004897

## 155 Model



Key	Description - 155 Model			Part Code
B	BURNER TRAY			
1-B	Burner Tray w/Gas Valve Natural			-
3-B	Burner Tray w/Gas Valve Propane			-
4-B	Burner			301210
	Burner Orifice Natural	No.49		350078
	Burner Orifice Propane	No.57		350083
C	CONTROLS			
1-C	Thermostat Pocket, High Limit			M3028
2-C	High Limit 60°C (140°F)			600893B
3-C	High Limit Manual Reset 102°C			M3029
5-C	Thermostat Control (Solid State)			600960
6-C	Potentiometer			600961
7-C	Temperature Sensor			600962
G	GAS VALVE			
1-G	Honeywell Gas Valve			M3265
2-G	L.P.G. Softlight Adapter			M3694
H	HEAT EXCHANGER			
1-H	Heat Exchanger Assembly (Complete)			066126
2-H	Inlet/Outlet Header			004963F
3-H	Return Header			004964F
4-H	Tube Bundle			004896F
6-H	Baffle Kit			303232
7-H	Bolt Kit			004889F
8-H	Header Gasket			800086B
9-H	Unitherm Governor			062234B
10-H	U.G. Retainer Spring			850254
11-H	Bypass Valve			062235B
12-H	Bypass Spring			850252
13-H	Drain Valve			500719
14-H	Sensor Well, Pool Temperature			003765F
15-H	Well Retaining Clip			300203
16-H	Inlet & Outlet Flange			003766F
17-H	Flange Gasket 1-1/2" Connections			800217
	Flange Gasket 2" Connections			800080B
J	J BOX/CONTROL BOX			
2-J	Ignition Control, Abbey			SPMB502/1
	Ignition Control, Robertshaw			SPMB502
3-J	Transformer 230V/24V			M650531
4-J	Toggle Switch			650761
M	MISCELLANEOUS COMPONENTS			
1-M	Pressure Switch			650634
2-M	Pressure Switch Tube Assembly			054374
3-M	Thermostat Knob			800201
4-M	Knob Stop			305138
5-M	DialPlate			M3060
8-M	Wire Harness IID			M3553
9-M	Thermal Fuse			651360
P	PILOT (Silver)		Part Code	PILOT (Black)
1-P	Pilot Natural/Propane	600799	5-P	Pilot Natural/Propane
2-P	Pilot Injector Natural	M3274	6-P	Pilot Injector Natural
	Pilot Injector Propane	601218		Pilot Injector Propane
3-P	Pilot Tube	400381	7-P	Pilot Tube
4-P	Hi-Tension Wire	651013	8-P	Hi-Tension Wire
				M3685
				M3687
				M3688
				M3703
				M3696
R-1	REFRACTORY			
1-R	Refractory Kit	FT/RR LT/RT		
			M700341 M700114	
S	SHEETMETAL			
1-S	Jacket Top			305703
2-S	Flue Collector			053243
3-S	Door Assembly			060146
4-S	Access Panel Group			-
5-S	Control Panel			
V	VENTING			
1-V	Stackless Top (Outdoor)			003710
2-V	Drafthood (Indoor)			003723

**185, 265 & 405 Model**



inject.tif


1-P

2-P

3-P

4-P

The diagram shows a mechanical assembly with four ports. Port 1-P is a top inlet/outlet. Port 2-P is a side inlet/outlet. Port 3-P is a bottom inlet/outlet. Port 4-P is a side inlet/outlet. The assembly includes a central body with a handle-like structure on top and a base with two knobs.







**185, 265 & 405 Replacement Parts List (continued)**

<b>Key</b>	<b>Description</b>	<b>185</b>	<b>265</b>	<b>405</b>
<b>P</b>	<b>PILOT (Silver)</b>			
1-P	Pilot Natural/Propane	600799	600799	600799
2-P	Pilot Orifice Natural	M3274	M3274	M3274
	Pilot Orifice Propane	601218	601218	601218
3-P	Pilot Tube	400607	400607	400607
4-P	Hi-Tension Wire	650998	650998	650998
<b>P</b>	<b>PILOT (Black)</b>			
5-P	Pilot Natural/Propane	M3685	M3685	M3685
6-P	Pilot Orifice Natural	M3687	M3687	M3687
	Pilot Orifice Propane	M3688	M3688	M3688
7-P	Pilot Tube	M3690	M3690	M3690
8-P	Hi-Tension Wire	M3696	M3696	M3696
<b>R-1</b>	<b>REFRACTORY</b>			
1-R	Refractory Common (Left & Right)	700461	700461	700461
2-R	Refractory Uncommon	M700462	M700463	700465
<b>S</b>	<b>SHEETMETAL</b>			
1-S	Jacket Top (Louvred)	065218	065219	065221
2-S	Flue Collector	065148	065149	065151
3-S	Door Assembly	065162	065163	065364
4-S	Access Panel Set (3 Pcs.)	-	-	-
5-S	Side Panel Right	307099		
6-S	Side Panel Left	307100		
7-S	Side Panel Cap	307098		
8-S	Rear Panel Kit (2 Pcs.)	-	-	-
10-S	High Limit Cover	307280	307280	307280
12-S	Up-Front Control Panel	065170	065171	065173
<b>V</b>	<b>VENTING</b>			
1-V	Indoor Stack Kit (Includes inner adapter panel)	006696	006697	006699
3-V	"Pagoda" Top	065310	065312	065311

**Certikin**

Station Lane  
Industrial Estate  
Witney  
Oxon.

**Tel. 01993 778855**

**Fax. 01993 703407**