


Single Step Manual


YA-DTB-01




Catalogue

1 (WARNINGS & INFO)	2
2 (CONTENT)	2
3 (TOOLS)	3
4 (INSTALLATION)	3 to 4
5 (ELECTRICAL INSTALLATION)	5
6 (OPEN & CLOSE)	5

1 WARNINGS & INFO



2 CONTENT



x6

M8 x 50 mm
GB/T 5780 /
DIN 933
A2


X12

M8
GB/T 95 /
DIN 125
A2

x6




M8
GB/T 889.2 /
DIN 985
A2










3 TOOLS



4 INSTALLATION


i





5 ELECTRICAL INSTALLATION

THULE STEP MANUAL with WARNING LAMP



6 OPEN & CLOSE

