

Repair instruction

Description: SC250 Pull handle
Part number: 50728
 Look for Service Centres, Point of Sale addresses and other information on: www.thetford-europe.com

Version:	1
Date:	June 2010
Tools required:	Flat head screwdriver



A

Turn waste holding-tank upside down.





B

Place flat head screwdriver underneath rib and take one complete rib out, if not broken yet.



C

Place screwdriver in handle and push down so that handle can be taken out completely.



D

At the end pull guide of the handle up and remove spring.



E

Assemble new pull handle and follow steps in reverse.