



LE766_C502C-X_1114-V03

		Spare part number	Spare part number	Spare part number	Colours available
1	Cover		90713		62, 127
2	Seat				
3	Bowl		90727		62, 127
4	Screw				
5	Sticker control knob		90725	90724	62, 127
6	Control PCB		<i>C-model</i>	<i>X-model</i>	
7	Control knob		<i>(before 90701)</i>	<i>(before 90709)</i>	
8	Cosmetic cover straight Cosmetic cover curved				
9	Water level sensor (<i>X-model only</i>)	90702			
10	Bench welded				
11	Cap waterfill funnel	16848			16
12	Waterfill funnel		90710	90719	
13	O-ring		<i>waterfill funnel</i>	<i>waterfill funnel</i>	
14	Waterfill elbow		<i>150mm</i>	<i>180mm</i>	
15	O-ring				
16	Tube PVC				
17	Drain connector				
18	Sight tube				
19	Clip sight tube	90711	90703		
20	Drain tube				
21	Tunnel				
22	Screw				
23	Base				
24	Pocket cover				
25	PCB cover				
26	Main PCB	90704 <i>C-model</i>	90712 <i>X-model</i>		
27	Retaining plate				
28	Magnet				
29	Magnet basket				
30	Flange lock				
31	Bushing				
32	Saddle		51802		
33	Spring				
34	Bracket				
35	Shaft				
36	Link				
37	Drain plug				
38	O-ring				
39	Blind plug water fill				
40	Pump	90714			
41	Water supply tube				
42	Nozzle		90705		127
43	O-ring				
44	Wiring harness	90720 <i>C-model</i>	90721 <i>X-model</i>		
45	Bayonet	90726			62



LE757_C503L_0518-V03

		Spare part number	Spare part number	Colours available
1	Cover		90713	62, 127
2	Seat			
3	Bowl		90727	62, 127
4	Screw			
5	Sticker control knob		90723	62, 127
6	Control PCB		(before 90715)	
7	Control knob			
8	Cosmetic cover straight Cosmetic cover curved			
9	Bench welded			
10	Base			
11	Tunnel			
12	Screw			
13	Pocket cover			
14	PCB cover			
15	Main PCB	90716		
16	Retaining plate			
17	Magnet			
18	Magnet basket			
19	Flange lock			
20	Screw			
21	Bushing			
22	Saddle		51802	
23	Spring			
24	Bracket			
25	Shaft			
26	Link			
27	Wiring harness	90722		
28	Water supply tube			
29	Hose clamp		90717	
30	Solenoid valve			
31	Hose nut			
32	Hose barb			
33	O-ring		90718	
34	Nozzle			
35	Water supply tube			
36	Water supply tube			
37	Bracket			
38	Screw			
39	Vacuum breaker	16833		
40	Screw			



LE758_C500-WHT_1114-V02

		Spare part number	Spare part number	Spare part number	Colours available
1	Sliding cover	32301			06
2	Blade opener	32300	32331 <i>mechanism right</i>	32332 <i>mechanism left</i>	16
3	Washer				
4	Seal parker				
5	Mechanism retainer				
6	Holding tank plate Left hand version				
6A	Holding tank plate Right hand version	32302			06
7	Seal mechanism	32328			06
8	Seal mechanism	50724			
9	Lip seal	23721			
10	Seal plate				
10	Screw				06
11	Blade	50731			
12	Bearing				
13	Blade arm				
14	Bushing				
15	Screw				
16	Blade driver				
17	Support track				
18	Screw				
19	Retainer	90706			
20	Magnet				
21	Float arm				
22	Upper automatic vent				
23	Seal	23722			06
24	Foam				
25	Pour out spout		32306		06
26	Measuring cup	25810			16
27	O-ring				
28	Pull handle				
29	Pull handle bushing right		51805		16
30	Pull handle bushing left				
31	Spring				
32	Waste-holding tank complete		90707 <i>right hand version</i>	90708 <i>left hand version</i>	06
33	Tank lock clip	51801			16
34	Wheel				
35	Wheel bearing right		32308		06
36	Wheel bearing left				
37	Wheel bracket				
38	Vent seal				
39	Spring		32307		16
40	Vent button				

		Spare part number	Spare part number	Spare part number	Colours available
41	Handle				
42	Screw				
43	Handle cover				