


LE1363_SOH74XXX

		Spare part number	Spare part number	Colours available
1	Glass lid (BK : smoked black)	SSPA0234		.BK
	Glass lid (SBK : solid black)	SSPA0233		.SBK
2	Glass lid hinges (2x)	SSPA0010		
3	Pan support	SSPA0967		
4	Pan support clips (4x)	SSPA0041		
	Pan support clips (50x)	SSPA0042		
5	Bump stops (2x)	SSPA0040		
6	Burner assy medium	SSPA0114		
7	Burner assy large	SSPA0123		
8	Spark electrode (4x)	SSPA0310		
9	Thermocouples hob		For lid shut off	
	Front left	SSPA0675	SSPA0671	
	Front right	SSPA0675	SSPA0671	
	Rear left	n.a.	n.a.	
	Rear right	SSPA0676	SSPA0670	
10	Gas tap oven	SSPA0452		
11	Gas tap grill	SSPA0472		
12	Spark ignition button (incl. switch)	SSPA0381		
13	Light switch <i>*not all models</i>	SSPA0591		
14	Gas tap burner (1x)	SSPA0432		
15	Control knobs	<i>Refer to page 3</i>		
16	Grill door	<i>Refer to page 3</i>		
17	Oven door	<i>Refer to page 4</i>		
18	Lower door <i>*only for 3/4 height</i>	<i>Refer to page 4</i>		
19	Glass, inner door	SSPA0253		
20	Oven door seal	SSPA0062		
21	Oven shelf	SSPA0980		
22	Grill pan	SSPA0991		
23	Oven lamp <i>*not all models</i>	SSPA0560		
24	Oven burner			
	<i>Production date: < 31-07-21 (E212Y...)</i>	SSPA0191		
	<i>Production date: ≥ 01-08-21 (E213Y...)</i>	SSPA0198		
25	Thermocouple oven	SSPA0642		
26	Electrode oven	SSPA0321		
27	Grill burner			
	<i>Production date: < 13-04-2015 (<E103S....)</i>	Not available		
	<i>Production date: ≥ 14-04-2015 (≥E104S....)</i>	SSPA0185		
28	Thermocouple grill			
	<i>Production date: < 01-07-2015 (<E182S....)</i>	SSPA0643		
	<i>Production date: ≥ 02-07-2015 (≥E183S....)</i>	SSPA0644		
29	Electrode grill	SSPA0321		
30	Spark generator	SSPA0399		

Control knobs

Control Knob sets



Spare part number

SSPA0901

Colours available


Matt Nickel (.MNK)
Satin Chrome (.SCR)

Set quantity


6

Cladding styles


No cladding



Side cladding



Behind handle cladding




Grill Doors


Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO3425.MIR2X	Clear	Mirror	No	N/A		Chrome
SMAO3425.BK4X	Clear	Black	Bottom Horizontal	N/A		Stainless
SMAO3425.BK1X	Clear	Black	No	N/A		Stainless

Oven door styles


Drop down oven doors










Left hinged oven doors



Right hinged oven doors



Drop down oven doors

Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO3445.BK/SVS10X	Clear	Faded dots	No	N/A		Satin
SMAO3445.MIR2X	Clear	Mirror	No	N/A		Chrome
SMAO3445.BK1X	Clear	Black	No	N/A		Stainless
SMAO3445.BK2X	Clear	Black	Yes	Bottom Horizontal		Stainless
SMAO3445.BK16X	Clear	Black	No	N/A		Chrome
SMAO3445.BK3X	Clear	Black	No	N/A		Brushed nickel
SMAO3445.BK9X	Clear	Black	No	N/A		Chrome satin

Lower doors

Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO3460.SS	Clear	Black	No	N/A	N/A	N/A
SMAO3460.MIR	Clear	Mirror	No	N/A	N/A	N/A
SMAO3460.BK	Clear	Black	No	N/A	N/A	N/A