





LE1328_SOV70XXX

		Spare part number	Spare part number	Colours available
1	Oven tap			
	<i>Production date: < 08-11-11 (E312M...)</i>	SSPA0452		
	<i>Production date: > 08-11-11 (E312M...)</i>	SSPA0451		
2	Knob	<i>Refer to page 3</i>		
3	Ignition switch (rectangular or round)	<i>Refer to page 3</i>		
4	Oven seal	SSPA0062		
5	Piezo ignition (n.a. on all models)	<i>Refer to page 3</i>		
6	Oven door	<i>Refer to page 4</i>		
7	Glass, inner door	SSPA0253		
8	Oven shelf	SSPA0982		
9	Grill pan	SSPA0993		
10	Oven burner			
	<i>Production date: < 31-07-21 (E212Y...)</i>	SSPA0191		
	<i>Production date: ≥ 01-08-21 (E213Y...)</i>	SSPA0198		
11	Thermocouple oven	SSPA0642	SSPA0623	
		< 08-11-2011 (E312M.....)	> 08-11-2011 (E312M.....)	
12	Electrode oven			
13	Spark generator (n.a. on all models)	<i>Refer to page 3</i>		


Control knobs

Control Knob			
	SSPA0934	SSPA0938	SSPA0920
Spare part number	SSPA0934	SSPA0938	SSPA0920
Colours available	Satin (.SA)	Black (.BK) Matt Nickel (.MNK)	Black (.BK)
Set quantity	2	1	3

Ignition switches


		
	Ignition switch rectangular	Piezo ignition
Description	Ignition switch rectangular	Piezo ignition
Spare part number	SSPA0381	SSPA0382

Spark generator


		
	4 terminals, 2 blanks	
Description	4 terminals, 2 blanks	
Spare part number	SSPA0303	

Cladding styles


No cladding



Side cladding



Behind handle cladding



Oven doors

Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO3435.BKX	Clear	Black	No	N/A		Black
SMAO3435.BK1X	Clear	Black	No	N/A		Steel
SMAO3435.BK5X	Clear	Black	Brushed stainless	Sides		Steel
SMAO3435.BK11X	Clear	Black	Linen stainless	Sides		Steel
SMAO3435.BK13X	Clear	Black	Brushed stainless	Sides		Black
SMAO3435.MIR1X	Mirror	Black	No	N/A		Steel
SMAO3435.MIR6X	Mirror	Black	No	N/A		Chrome
SMAO3435.SSX	Sparkling stainless	Black	No	N/A		Black