




LE1461_SHB142XX

		Spare part number	Colours available
1	Glass lid (Smoked black)	SSPA0220	.BK
	Glass lid (Solid black)	SSPA0221	.SBK
2	Hinge	SSPA0009	
3	Pan support (Enameled Black) x1	SSPA0965	
4	Pan support (Chrome Plated)	SSPA0975	
5	Pan support clip x4	SSPA0041	
	Pan support clip x50	SSPA0042	
6	Hotplate (800W)	SSPA0550	
7	Burner assy medium		
	Production date: < 10-06-12 (E161N...)	SSPA0114	
	Production date: ≥ 11-06-12 (E162N...)	SSPA0812	
	Burner assy small		
	Production date: < 10-06-12 (E161N...)	SSPA0102	
	Production date: ≥ 11-06-12 (E162N...)	SSPA0811	
8	Bezel	SSPA0073	
9	Hotplate switch	SSPA0580	
10	Gas tap burner		
	Production date: < 10-06-12 (E161N...)	SSPA0432	
	Production date: ≥ 11-06-12 (E162N...)	SSPA0430	
	Production date: ≥ 02-10-17 (E275U...)	SSPA0433	
11	Knobs	<i>Refer to page 3</i>	
12	Thermocouple (Knobs on the left side)		
	Front left	SSPA0675	
	Front right	SSPA0676	
	Rear Left	n.a.	
	Rear Right	SSPA0676	
	Production date: ≥ 11-06-2012 (≥ E162N...)		For lid shut off
	Front left	SSPA0680	SSPA0685
	Front right	SSPA0682	SSPA0687
	Rear Left	n.a.	n.a.
	Rear Right	SSPA0682	SSPA0687
	Thermocouple (Knobs on the right side)		
	Front left	SSPA0676	
	Front right	SSPA0675	
	Rear Left	n.a.	
	Rear Right	SSPA0675	
	Production date: ≥ 11-06-2012 (≥ E162N...)		For lid shut off
	Front left	SSPA0682	SSPA0687
	Front right	SSPA0680	SSPA0685
	Rear Left	n.a.	n.a.
	Rear Right	SSPA0680	SSPA0685
13	Electrode		
	Production date: < 10-06-12 (E161N...)	SSPA0312	
	Production date: ≥ 11-06-12 (E162N...)	SSPA0322	

Control knobs

Control Knob			
Spare part number	SSPA0935	SSPA1200	SSPA1201
Colours available	Chrome (.CR) Satin (.SA)	Black (.BK)	Matt Nickel (.MNK)
Set quantity	5	5	4