








LE1328_SOV70XXXX

		Spare part number	Spare part number
1	Oven tap		
	<i>Production date: < 14/03/2011 (E073M...)</i>	SSPA0452	
	<i>Production date: ≥ 14/03/2011 (E073M...)</i>	SSPA0451	
2	Grill tap		
	<i>Production date: < 14/03/2011 (E073M...)</i>	SSPA0472	
	<i>Production date: ≥ 14/03/2011 (E073M...)</i>	SSPA0470	
3	Control knobs	<i>Refer to page 3</i>	
4	Ignition switch	SSPA0381	
5	Light switch *if fitted	SSPA0591	
6	Bump Stops	SSPA0040	
7	Grill door	<i>Refer to page 4</i>	
8	Oven door	<i>Refer to page 4</i>	
9	Lower door	<i>Refer to page 4</i>	
10	Inner door glass	SSPA0253	
11	Oven seal	SSPA0062	
12	Oven shelf	SSPA0980	
13	Grill pan (full assembly including trivet and handle)	SSPA0993	
14	Oven lamp *if fitted	SSPA0560	
15	Oven burner	SSPA0191	
16	Oven thermocouple (including electrode)		
	<i>Production date: < 14/03/2011 (E073M...)</i>	SSPA0642	
	<i>Production date: ≥ 14/03/2011 (E073M...)</i>	SSPA0623	
17	Oven spark electrode (including part 21)	SSPA0321	
18	Spark generator	<i>Refer to page 3</i>	
19	Grill burner		
	<i>Production date: < 13/04/2015 (E103S...)</i>	No longer available	
	<i>Production date: ≥ 13/04/2015 (E103S...)</i>	SSPA0185	
20	Grill thermocouple		
	<i>Production date: < 29/10/07 (2007090212)</i>	SSPA0157	
	<i>Production date: < 14/03/11 (E073M...)</i>	SSPA0643	
	<i>Production date: ≥ 14/03/11 (E073M...)</i>	SSPA0645	
21	Grill spark electrode (including part 17)	SSPA0321	

Control knobs


				
Control knob sets				
Spare part number	SSPA0920	SSPA0934	SSSPA1203	SSPA0916
Colours available	Black(.BK)	Chrome- Black(.CR/BK) Satin Black(.SA/BK)	Chrome(.CR)	Brushed Nickel (.BNK)
Set quantity	3	3	3	3

Spark generators


			
Description	2 terminals	4 terminals, 2 blanks	6 terminals
Spare part number	SSPA0302	SSPA0303	SSPA0399

Cladding styles


No cladding



Side cladding



Behind handle cladding



Grill doors

Spare part number	Glass	Print	Cladding	Cladding position	Handle style	Handle colour
SMAO3415.BK2X	Clear	Black	No	N/A		Stainless
SMAO3415.BK18X	Clear	Black	No	N/A		BNK
SMAO3415.BK23X	Clear	Black	No	N/A		BNK
SMAO3415.BKX/SVS5X	Clear	Black & Silver	No	N/A		BNK
SMAO3415.MIR1X	Mirror	N/A	No	N/A		Stainless
SMAO3415.SS3X	Clear	Silver	No	N/A		Black

Drop Down oven doors

Spare part number	Glass	Print	Cladding	Cladding position	Handle style	Handle colour
SMAO3435.BK1X	Clear	Black	No	N/A		Stainless
SMAO3435.BK20X	Clear	Black	No	N/A		BNK
SMAO3435.BK23X	Clear	Black	No	N/A		BNK
SMAO3435.BKX/SVS5X	Clear	Black & Silver	No	N/A		BNK
SMAO3435.MIR1X	Mirror	N/A	No	N/A		Stainless
SMAO3435.SSX	Clear	Silver	No	N/A		Black

Lower doors

Spare part number	Glass	Print	Cladding	Cladding position	Handle style	Handle colour
SMAO3450.BKX	Clear	Black	No	N/A	N/A	N/A
SMAO3450.BK/SVXS	Clear	Black & Silver	No	N/A	N/A	N/A
SMAO3450.MIRX	Mirror	N/A	No	N/A	N/A	N/A